

DK-6.5 Professional Speaker System



SPECIFICATIONS

Туре	2-way 2-unit system
Enclosure	Bass-reflex Type
Drivers	
Woofer	6.5"
Tweeter	
Nominal Impedance	8 Ohms
Frequency Response	
Power Handling	100Watts (Peak)
	60Watts (RMS)


Sensitivity 90dB/W at 1m
Crossover Frequency 4KHz
Dimensions 310mm(L) \times 205mm(W) \times 190mm(D)
Net Weight 3.6kg/pce
Package430mm(L) \times 390mm(H) \times 270mm(W)
Gross Weight 8.3kg/Pair
Accessories
Owner's Manual 1 pce
Wall Mounts 2 pcs
Flying Nut


CAUTION


- Do not install the appliance on or at unstable location.
- If the loudspeaker is not identified as magnetically shielded, please do not place it near the TV set in order to avoid magnetizing the TV screen.
- Do not place the loudspeaker in a location where it will be exposed to direct sunlight, high temperature or high humidity.
- Be sure to turn off your amplifier before connection or disconnecting speakers.
- Do not operate the speaker with power exceeding limitation, as it may damage the speaker.
- Do not turn up the volume too much when a graphic equalizer is used to turn up for a higher sound level.
- Do not turn up for a higher sound level with a lower power amplifier, or it may damage tweeter speakers. Keep the volume control of your amplifier at the low position when first turn it on to avoid damaging.
- Use a clean dry cloth to wipe off dirt.
- Do not use volatile solvents such as alcohol, paint thinner, gasoline or benzene, etc to clean the cabinet.



Owner's Manual








Angle adjustable

Speaker Stand

CAUTION

- Before installation, check the ceiling or wall to confirm that it is strong enough to stand with the weight of the speaker system.
- **BFAudioPro** can not assume the responsibility against accidents caused by the drop of speaker system due to insufficient mounting strength or to any defect in installation.
- If the material or thickness of a ceiling or wall can not be confirmed, consult a professional specialized in installation.





CONNECTIONS

- 1. Before connecting your loudspeaker with amplifier, make sure the amplifier and every associated equipment is turned off.
- 2. Note that whether the impedance of the loudspeaker matches with that of the amplifier.
- 3. Align the (+) and (-) polarities for the left (L), right (R) and connect the speaker terminals on the amplifier.
- 4. If the polarities of left and right are not aligned properly, the quality of the reproduced sound, the ambience and the feeling of direction will be markedly impaired.

